



# DENTAL SPA™



## UV Toothbrush Sanitizer

VZL100 Product Series

### USING YOUR DENTAL SPA

Before use, unscrew the battery door compartment and insert 3 “AA” batteries.

1. Push the small white clip to open the lid of your Dental Spa. Remove the cup and contour tray from the inside compartment by lifting straight up and out
2. Set the curved tray aside.
3. Fill the cup with water to the

indicator line.

4. Place the cup back into the Dental Spa. When seated, push down firmly for a tight fit.
5. Place items to be cleaned directly into the cup so they are submersed in the water. If you are cleaning smaller items, you can place them on the curved tray and then insert into the cup of water.
6. Close the lid of the Dental Spa.
7. Two options:

### FOR UV + SONIC CLEANING:

Press the “UV + Sonic” button to start. The LED indicator light will flash red and blue. The vibration will turn off automatically after 5 minutes, but the UV light will stay on longer for an extra 15 minutes.

### FOR UV CLEANING ONLY:

Press the “UV Only” button to start. The LED indicator light will flash blue. It will turn off automatically after 20 minutes.

**8. Manual Shut-Off:** To interrupt either cycle, simply press the function button and hold for 3 seconds.

**9.** After your Dental Spa cycle is complete, remove your items and discard the water from the cup. Rinse and dry the cup so it’s ready for the next use!

### SAFEGUARDS

- Children should be properly supervised.
- Do not place unit where it can be in danger of falling into sinks, toilets or bathtubs.
- Always make sure your Dental Spa lid is closed before using. To prevent eye injuries from looking directly at the lit UV bulb, it will make a forced shutdown by opening the lid.
- Do not look directly at the lit bulb.
- Build-in power save timer shuts the power automatically after 20 minutes when you turn it on.
- If the unit is dropped or damaged, or if the unit remains on beyond the 20-minute sanitizing cycle, please call or email customer service.

### CLEANING & CARE

- Remove and rinse the internal cup and contour tray after each use.
- NEVER rinse the base, place it under running water, or immerse it for any reason. To clean, simply wipe with a moist cloth or sponge as needed.

### TROUBLE SHOOTING

Please contact us at Violife... but first, check the following:

- Did you press the blue buttons hard enough?
- Are the batteries in need of replacement?

If the problem persists, please call Violife directly, not the catalog or store from which you purchased. We know your Violife unit better than anyone, and we’re here to help you. send email to [customerservice@violife.com](mailto:customerservice@violife.com) or call 1-888-882-2367. Visit us on the web at [www.violife.com](http://www.violife.com).